


**Inax Toilet Parts**

Item No.	Part Number	Part Name	Item No.	Part Number	Part Name
1.	C-90U	Toilet Bowl	10.	A-175	Overflow Pipe - Chrome
2.	T-290U	Water Tank & Cover	11.	74-01-3	Overflow Floor Escutcheon
3.	TF-814G-A	Water Tank Mounting Bolt	12.	TF-490A	Operating Levers
4.	CF-6AKT	Toilet Seat - Inax	13.	A-1277	Cable Conduit
4a.	800TT	Toilet Seat - Bemis	14.	CF-930	Flap Cable Assembly
5.	TF-592B	Inlet Water Valve & Float	15.	CF-920	Flap Assembly (see next page)
5a.		Inlet Water Valve Float Only	16.	WG-90	Sticky Gasket - Flap Lid to Bowl
6.	TF-490C	Flush Ball Assembly	17.	41-216	Fixing Bolt - Flap Lid to Bowl
7.	50-628	Gasket - Toilet Tank to Bowl	18.	50-314	Mounting Gasket to Waste Pipe
8.	TF-75W-YR	Water Tank Drain Valve	19.	B-280	Wastepipe Support Ring
9.	A-174	In-tank Overflow Pipe	20.	KF-30D	Toilet Mounting Bolt



**Inax Toilet Parts Continued  
Flap Assembly Parts**

Item No.	Part Number	Part Name
<b>15.</b>	<b>CF-920</b>	<b>Flap Assembly Includes:</b>
15-1.	59-77	Screw-in Seal Ring
15-2.	50-636	Rubber Flap Seal - Pop-in
15-3.	75-111	Flap Lid w/o screws
15-3a.	A-1010	Flap Lid w/ screws, seal and retainer ring
15-4.	41-212	Screws for Flap Arm Bracket
15-5.	35-42	Flap Arm Bracket
15-6.	64-51	Clip for Flap Weight
15-7.	75-112	Flap Weight
15-8.	B-472	Flap Box
15-9.	66-20	Toilet Flap
15-10.	73-46	Flap Weight Arms
15-11.	18-236	Flap Retaining Washer
15-12.	72-35	Flap Retaining Clip
15-13.	41-213	Screws - Cable Bracket (2); Flap Lid (6)
15-14.	36-96	Cable Bracket